



# Martin-Till

## Weight Transfer System

Transfer of weight from the center of the planter to the wings reduces compaction and ground pressure, more evenly distributing the weight to where it is needed most. Providing a level toolbar promoting uniform planting depths along all row units.



1770 WTS (900083)



1790/1795 WTS  
(900079/900072)



**Deere 1770/1775**  
**12 , 16 & 24 Row Planters**



**Deere 1790/1795**  
**12 & 16 Row Planters**

- Bolt on brackets
- Grade 8 mounting hardware
- Industry standard durable hydraulic valve
- Rugged Electronic PWM control box allows for fine tuning of industry standard hydraulic valve